



**ACOUSTICAL**

*Sound Solutions for Over 40 Years*

**SURFACES INC.**

Soundproofing | Acoustics | Noise & Vibration Control

# INSTALLATION INSTRUCTIONS

## N.S. QFA-11

---

*Material typically required to complete installation:*    *QFA-11, self-tapping screws or nails appropriate for substrate, or other framing material (optional).*

- 1.** Determine the area to be covered.
- 2.** If you choose to, for ease of installation, you may frame over the existing wall with furring strips or other framing material.
- 3.** If the material is provided in bound pieces (no grommets along any edge).
  1. Using a self-tapping screw that is appropriate for the substrate screw directly through the QFA-11 material into the wall or framing material.
  2. You may use a washer, between the screw and the QFA-11, to help secure the material in place.
- 4.** If the material is provided in curtain panel form (with edges bound and grommets along at least one edge).
  1. Using a self-tapping screw that is appropriate for the substrate screw through the grommets in the QFA-11 curtain panel into the wall or framing material.
  2. Place a washer, with an ID smaller than that of the screw head, on top of the grommet you are securing through.